

Midicake ARP - Angle Stand Fitting Instructions

- 1) Unplug the USB power and other cables.
- 2) Turn ARP upside down and place on a desk
- 3) Position the Angle Stand over the rear mounting holes, as shown below
- 4) Insert the two M4 Screws and tighten with a Philips or Cross Head Screwdriver
- 5) Turn ARP over and ensure the Angle Stand not loose
- 6) Enjoy!

If you have any issues or questions, please email hello@midicake.com

